



FuelCel

Light weight composite fuel tanks

Yamaha R6 '06-'07 & '08

**Installation instructions
TANK GUARDS**

INSTALLATION INSTRUCTIONS

- A previously dented tank does not have the original shape and these guards might have a hard time fitting properly since they are molded to conform to the stock shape of the tank.
- Remove the Yamaha tuning fork logos from the tank, once the guards are mounted then you can double stick tape them on to the guards after painting.
- Put the guard in place and use the rear plastic cover 5 x 12mm bolt and washer provided to hold the back corner down to the tank.
- On the 06-07 model years the guard goes over the plastic cover in back.
- On the 08 and newer model years the guard goes under the plastic cover.
- Form the guard snugly over the shape of the tank towards the frond securing it in place temporarily with tape.
- On the 06-07 mark where the lower front tank mounting fasteners are and cut a small relief hole out of the plastic side covers so you can remove these fasteners after the tank guards are mounted, see pictures below.
- Use the front holes in the guards as a template to drill into the tanks front cover after insuring the guard's best fit on the tank's contour.
- Use the fasteners provided to secure the front of the guards. Be sure to have a washer between the nut and the head of the bolt sandwiching the guard and the plastic cover.
- If the edge of the guard seams to catch your leathers use some racers tape to cove the transition of the guard to the tank.
- **WARNING;** These guards provide multiple layers of KEVLAR over the most vulnerable part of the R6 tank, though this adds to the durability of the tank it no way a guarantees the steel tank to be impervious to impact or abrasion related failures.
- This R6 tank guards are sold without Warranty expressed or implied by the manufacturer and its final suitability for use is determined by the operator of the motorcycle on which they is installed. 11/02/10

